CLEANING AND DISINFECTING RADIOS & ACCESSORIES



RECOMMENDATIONS FOR RADIO, BODY-WORN CAMERA, AND ACCESSORY CARE

592 W Perry Road Ligonier, Indiana 46767 | 800 - 475 - 3320 | www.erswireless.com

Below are the Motorola Solutions recommended cleaning guidelines for radios, body-worn cameras, and accessories.

CLEANING

- 1. Apply 0.5% detergent-water solution with a cloth.
- 2. Use a stiff, non-metallic, short-bristled brush to work loose dirt away from the device.
- 3. Use a soft, absorbent, lintless cloth or tissue to remove the solution and dry the device.

DISINFECTING

- 1. Wipe device down with overthe-counter isopropyl alcohol (rubbing alcohol) with at least 70% alcohol concentration.
- 2. Alcohol should never be applied directly to the device. Apply to a cloth, then wipe down the device.
- 3. The effects of certain chemicals and their vapors can have detrimental effects on plastics and the metal platings.





